

Protec Covers

Bailey Single Awning Towing Cover Fitting Guide



These fitting instructions are aimed as a guide to the best way that we've found to fit your Protec cover.

Before fitting, it is essential that the front of your caravan is clean and free of grit. If any grit or dirt becomes trapped between the cover and the caravan, there is a risk of scratching.

Towing covers are designed for towing purposes only; we do not advise that they are kept on the caravan for storage.

Contents

- Towing Cover Centre Panel
- Side Panels
- Storage Bag
- A-Frame Strap
- SNAD Fasteners
- Bungee Cords

Fitting Instructions

1. Unpack your towing cover and locate the pieces. You will have one centre panel, one nearside panel with awning piping, and one offside panel with

press studs.

2. Slide the piece with awning piping into the nearside awning channel. Making sure the grey side of the fabric is facing you and that the fabric and buckles are sitting on the front of the caravan, not the side.
3. Attach all three panels together with the adjustable buckles, making sure they're the correct way around. (the clear panels and a-frame cut-out will be at the bottom of the cover)
4. Attach the SNAD fasteners to the press studs on the offside panel without removing the adhesive backing.
5. Line up the cover making sure the lights are visible, and starting from the top, remove the adhesive backing of the SNAD fastener and attach it to the offside of the caravan one by one. **TIP:** This step is only required the first time fitting the cover; the SNAD pads will stay on the caravan permanently, but if you do need to remove them, this can be done by levering a credit card-sized object underneath.
6. Adjust and tighten the buckles as needed, being sure not to over-tighten. Trim off any excess webbing from the strap and seal with a lighter or match so that the excess does not flap against your caravan during transit.
7. Attach the a-frame strap to the two buckles located at each side of the tow hitch, passing it underneath the tow hitch assembly.
8. Line up the bottom corners of the cover and attach a bungee cord at each corner before attaching the other side of the bungee cord to your front corner steadies.

Care Instructions

Clean the cover using warm water with a soft brush, a hosepipe may be used but we do not advise the use of power washers.

DO NOT use any detergents or chemicals, as this will block the pores and affect the hydrophobic properties of the fabric. However, if you have any stubborn stains that will not be removed with just warm water, you can add soap flakes (the type you would use to hand-wash clothing) to the warm water to aid the washing.