

Protec Covers

Motorhome Cover Fitting Guide



These fitting instructions are aimed as a guide to the best way that we've found to fit your Protec cover.

Before starting, it is essential that you remove any sharp objects that may be on your motorhome (such as aerial spikes or antenna) and ensure your motorhome is clean and free of any puddles of water. Failure to do so can result in damage to your motorhome's paintwork as dirt may get trapped between the cover and 'the van.

Contents

- Protec Cover
- Storage Bag
- 2 x fitting poles
- Straps
- Pipe Lagging
- Spare Fabric

Fitting Instructions

1. Unpack your cover and locate the foam pipe lagging. If necessary, place this on any sharp edges/protrusions such as solar panel corners, etc.
2. Identify the front and rear of the cover by the logo (the logo will be at the front of the cover). Position the cover in front of the vehicle with the rear panel facing the motorhome.
3. Roll up the Easy-Fit panel and secure it in place with the Velcro tab to ensure it doesn't get in the way when fitting.
4. Locate the D-rings at the back of the cover and place a pole into each D-Ring. Extend the pole as needed and twist it to lock.
5. Using the poles, lift and push the cover so it is over the front of the motorhome and resting on the roof of the vehicle.
6. Walk and push the cover along the length of the motorhome with the pole in front of you at a 45-degree angle. If two people are fitting the cover, do this with one person at each side with a pole each. If fitting the cover solo, push the cover along alternating sides as you make your way towards the back.
7. Locate your bag of straps and identify the two longer straps. These are to be fastened to the buckles situated at the front and rear of the cover. Tighten as needed but be sure not to overtighten.
8. Secure the remaining straps underneath the width of your motorhome and tighten them as necessary, being sure not to over-tighten them. **TIP:** The buckle can be attached to the end of a pole using an elastic band in order to push the strap underneath the width of the motorhome to reach the other side.

Care Instructions

Clean the cover using warm water with a soft brush, a hosepipe may be used but we do not advise the use of power washers.

DO NOT use any detergents or chemicals, as this will block the pores and affect the hydrophobic properties of the fabric. However, if you have any stubborn stains that will not be removed with just warm water, you can add soap flakes (the type you would use to hand-wash clothing) to the warm water to aid the washing.

Weather Advisory: Protec Covers strongly recommends removing your full caravan cover in instances of extreme weather (extremely strong winds, hurricanes, etc.)