

# Protec Covers

## Universal Towing Cover Fitting Guide



These fitting instructions are aimed as a guide to the best way that we've found to fit your Protec cover.

Before fitting, it is essential that the front of your caravan is clean and free of grit. If any grit or dirt becomes trapped between the cover and the caravan, there is a risk of scratching.

Towing covers are designed for towing purposes only; we do not advise that they are kept on the caravan for storage.

### Contents

- Towing Cover Centre Panel
- Side Panels
- Storage Bag
- A-Frame Strap
- Tear Aid Pieces

## Fitting Instructions

1. Unpack your towing cover and locate the pieces. You will have one centre panel and two side panels.
2. Slide each side panel into the awning channels, making sure the white side of the panel is touching the caravan.
3. Attach the centre panel to the two side panels with the adjustable buckles, starting at the top and making your way to the bottom.
4. Adjust the cover and tighten the buckles as needed, being sure not to over-tighten. Trim off any excess webbing from the strap and seal with a lighter or match so that the excess does not flap against your caravan during transit.
5. Mark with chalk or pencil the area where your bottom running lights/reflectors are by circling around the light.
6. Carefully puncture a hole in the centre of the circles you have marked on the cover, then cut out this circle using scissors. (cutting this hole may be easier to do by removing the cover first)
7. If you find the side panels are obstructing the view of your lights, you can also mark these and cut a section of them away as you did with the centre panel.
8. Cut the Tear Aid pieces to the needed size and stick this to the inside and outside of the centre panel over the holes you have just cut. You do not need to put the Tear Aid on the side panels.
9. Attach the a-frame strap to the two buckles located at each side of the tow hitch, passing it underneath the tow hitch assembly.

## Care Instructions

Clean the cover using warm water with a soft brush, a hosepipe may be used but we do not advise the use of power washers.

**DO NOT** use any detergents or chemicals, as this will block the pores and affect the hydrophobic properties of the fabric. However, if you have any stubborn stains that will not be removed with just warm water, you can add soap flakes (the type you would use to hand-wash clothing) to the warm water to aid the washing.